

# Pendant Station(SH / 14 D)



## SH / 14 D Push Buttons:

12 + 2 - Two Speed

### Description :

12 Push Button with (1 NO + 1 NO)

Progressive Contacts



+ 1 Emergency Stop with 1 NC Contact

+ 1 Start /Alarm with 2 NO Contacts



SH / 14D		SH /14D1		SH / 14D2		SH / 14D3	
START	STOP	START	STOP	START	STOP	START	STOP
ALARM		ALARM		ALARM		ALARM	
UP	DOWN	UP	DOWN	UP	DOWN	UP	DOWN
UP	DOWN	UP	DOWN	UP	DOWN	UP	DOWN
FORWARD	REVERSE	FORWARD	REVERSE	FORWARD	REVERSE	FORWARD	REVERSE
FORWARD	REVERSE	FORWARD	REVERSE	FORWARD	REVERSE	FORWARD	REVERSE
LEFT	RIGHT	LEFT	RIGHT	LEFT	RIGHT	LEFT	RIGHT
LEFT	RIGHT	LEFT	RIGHT	LEFT	RIGHT	LEFT	RIGHT

Single Speed      Multi Speed



Weight : 1390 gm.